

Lift the top enough to clear the front lugs then push back a couple of cm to disengage the rear clips. Or, like me, just heave it up in the air and break the rear clips.



Remove the top concrete block. 13mm socket here.



Push down on the blue lever to remove the powder tray.

