


This is so you can remove the clip that holds the water outlet pipe onto the drain pump



Top inner front panel comes off next. Three screws only, and the top one (it is on the right) is different to the other two. Don't get them muddled. There is no top left screw.



The top right screw is a machine screw with a fine thread.

